


BOSTITCH®

P6C-8AD (also known as JB600) PNEUMATIC STAPLING PLIER




TOOL PARTS ILLUSTRATION

▲WARNING:

BEFORE PERFORMING REPAIRS ON THIS TOOL, ALL OPERATORS SHOULD STUDY THIS ILLUSTRATION, AS WELL AS THE PARTS LIST AND OPERATION AND MAINTENANCE MANUAL. OPERATORS SHOULD UNDERSTAND AND FOLLOW ALL SAFETY WARNINGS AND INSTRUCTIONS. KEEP THIS ILLUSTRATION WITH THE TOOL FOR FUTURE REFERENCE. IF YOU HAVE ANY QUESTIONS, CONTACT YOUR BOSTITCH REPRESENTATIVE OR DISTRIBUTOR.

P6C-8AD (also known as JB600)

Pneumatic Stapling Plier



P6C-8AD (also known as JB600) Pneumatic stapling plier

NO.	DESCRIPTION	REPLACEMENT PART NUMBER	Q'ty
1	PIVOT PIN	JB600-10	1
2	E-RING	85018	4
3	MOUNT BRACKET ASSY INCLUDES; MOUNT FRAME AND RIVET	JB600-1	1
4	COVER ASSY INCLUDES; COVER AND COVER ANCHOR	JB600-2	1
5	OPER LEVER ASSY INCLUDES; LEFT & RIGHT LEVERS, ROLL PIVOT PIN, AND CAM ROLLER	JB600-7	1
6	CYLINDER ASSEMBLY INCLUDES; WARNING LABEL (159912)	JB600-11	1
7	DRIVER BLOCK	JB600-4	1
8	CAM ROLLER	JB600-8	3
9	LEVER PIVOT PIN	JB600-13	1
10	SET SCREW	JB600-17	1
11	RETAINING SCREW	JB600-19	2
12	HEX NUTS	JB600-18	2
13	MACHINE PIN BUSHING	JB600-5	2
14	ROLLER PIN	JB600-12	1
15	FLAT HEAD SCREW-COVER	JB600-16	2
16	P6C-8 MODIFIED INCLUDES LOADING LABEL (103339)	JB600-14	1

IP1254REVA 01/07

TO BE USED WITH OPERATION AND MAINTENANCE MANUAL 175619.