



# EWS-202

## Air Impact Screwdriver



## OPERATING & MAINTENANCE MANUAL




**WARNING**

BEFORE USING THIS TOOL, STUDY THIS MANUAL TO ENSURE SAFETY WARNING AND INSTRUCTIONS.

KEEP THESE INSTRUCTIONS WITH THE TOOL FOR FUTURE REFERENCE.

AUGUST 2020

# 1/4" HEX. DRIVE SUPER POWERFUL IMPACT SCREWDRIVER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	XS10001	MOTOR HOUSING	21	XS10021	O-RING
2	XS10002	SPRING PIN	22	XS10022	CLAMP NUT
3	XS10003	AIR INLET	23	XS10023	O-RING
4	XS10004	TRIGGER	24	XS10024	HAMMER
5	XS10005	VALVE STEM	25	XS10025	HAMMER PIN
6	XS10006	VALVE BUSHING	26	XS10026	HAMMER CAGE
7	XS10007	O-RING	27	XS10027	ANVIL
8	XS10008	VALVE SPRING	28	XS10028	HAMMER CASE
9	XS10009	O-RING	29	XS10029	WASHER
10	XS10010	REVERSE LEVER	30	XS10030	RETAINING RING
11	XS10011	MOTOR GASKET	31	XS10031	STEEL BALL
12	XS10012	WASHER	32	XS10032	ANVIL BUSHING
13	XS10013	BALL BEARING	33	XS10033	EXHAUST DIFFUSER
14	XS10014	REAR END PLATE	34	XS10034	SCREW
15	XS10015	ROTOR	35	XS10035	O-RING
16	XS10016	ROTOR BLADE	36	XS10036	SPRING
17	XS10017	PIN	37	XS10037	BALL RETAINER
18	XS10018	CYLINDER	38	XS10038	DECORATION RING
19	XS10019	FRONT END PLATE	39	XS10039	IRON SHEET
20	XS10020	BALL BEARING	40	XS10040	DAMPING MATERIAL