



FSN3490-ST

Construction Nailer



OPERATING & MAINTENANCE MANUAL




WARNING

BEFORE USING THIS TOOL, STUDY THIS MANUAL TO ENSURE SAFETY WARNING AND INSTRUCTIONS.

KEEP THESE INSTRUCTIONS WITH THE TOOL FOR FUTURE REFERENCE.

AUGUST 2021



FSN3490-ST											
NOTE: When ordering spare parts, please state the part name and part number.											
Item	Part NO.	Description	Qty	Item	Part NO.	Description	Qty	Item	Part NO.	Description	Qty
1	100769	Hex.Soc.Flat Counter Sunk Hd. Bolt	1	33	100966	Spring Pin	4	65	100568	Screw Socket Hd M5*30	2
2	101330	Screw M5*12	2	34	100450	Seq. Trigger Valve	1	66	100638	Washer	2
3	101433	Exhaust Cover	1	35	100386	Seq. Trigger Unit	1	67	101096	Nut, Elastic Stop M5	2
4	100208	Screw Socket Hd M6*35	4	36	107003	Contact arm guide	1	68	104416	Hex.Soc.Hd.Bolt M6*14	1
5	100682	Spring Washer	4	37	100925	Hex.Soc.Hd.Bolt M8*28	4	69	100046	Plain Washer	2
6	101303	Cap	1	38	106092	Spring, Contact Arm	1	70	106071	Hex.Soc.Hd.Bolt M6*18	1
7	103443	Seal, Cylinder Cap	1	39	106076	Anchor Block Lock Nut	3	71	106097	Roll Pin	2
8	101331	Nut M6	1	40	104410	Contact Arm	1	72	106151	O-Ring	1
9	101332	Spacer	1	41	101387	Steel ball	1	73	100389	Spring	1
10	101308	Piston Stop	1	42	101388	Compression Spring	1	74	100685	Washer	1
11	101306	Spring	1	43	101389	Adjust dial	1	MOQ for items in the following categories is			
12	101312	O-Ring	1	44	106099	Contact Bolt	1	10pcs. order quantities under 10pcs for these			
13	101310	Head Valve Piston	1	45	104408	Front Contact Arm Unit	1	items will be adjusted accordingly			
14	101311	O-Ring	1	46	104097	E-Ring	1	1. Orings -- not included in the oring kits			
15	101314	O-Ring	1	47	101394	No Mar Pad	2	2. Screws, bolts			
16	104409	Main Piston Unit	1	48	104418	Contact Arm Cover	1	3. Pins - roll pin, solid pins			
17	101316	Cylinder Seal	1	49	100683	Bushing	1	4. Standard washers -- not special washers.			
18	101321	Cylinder	1	50	104413	Magazine	1	5. Nuts			
19	101320	O-Ring	1	51	104429	Steel Channel	1				
20	101322	Check Valve	1	52	104427	Pusher	1				
21	101319	O-Ring	1	53	106050	Pin	1				
22	101318	Cylinder Ring	1	54	106053	Spring, Feed Piston	1				
23	101323	Bumper	1	55	106054	Spacer Ring	1				
24	104426	Frame	1	56	106062	Bushing	1				
25	100327	O-Ring	1	57	106061	Stop Lever	1				
26	104090	End Cap	1	58	106063	Spring	1				
27	104091	Hook	1	59	106058	Protective Cover	1				
28	104095	O-Ring	1	60	106064	Hex.Soc.Hd.Bolt M4*20	1				
29	104092	Washer	1	61	100654	Lock Nut	1				
30	104093	C-Ring	1	62	106067	Nut M5	1				
31	101354	O-Ring	1	63	104428	Positioning sheet	1				
32	104415	Nose	1	64	106066	Screw M6*14	2				