



PN80

Pneumatic Coil Nailer



OPERATING & MAINTENANCE MANUAL




WARNING

BEFORE USING THIS TOOL, STUDY THIS MANUAL TO ENSURE SAFETY WARNING AND INSTRUCTIONS.

KEEP THESE INSTRUCTIONS WITH THE TOOL FOR FUTURE REFERENCE.

AUGUST 2021



PN80.B01	D	2017/03/08
----------	---	------------

PN80		<i>NOTE: When ordering spare parts. Please state the part name and part number.</i>					
Item	Part NO.	Description	Q'ty	Item	Part NO.	Description	Q'ty
1	100009	Screw	1	53	100197	Check Pawl	1
2	100010	Exhaust Cover Holder	1	54	100084	Spring	1
3	100011	O-Ring	1	55	100083	Door Latch	1
4	100243	Exhaust Cover	1	56	100269	O-Ring	1
5	100014	Exhaust Cover Seal	1	57	100098	O-Ring	1
6	101966	Cylinder Cap Unit	1	58	100270	Feed Piston	1
7	100127	Screw	4	59	100206	Compression Spring	1
8	100143	Protector	2	60	100205	Feed Piston Stop	1
9	100144	Cylinder Cap Seal	1	61	100207	Sprig Collar	1
10	100289	Spacer · Exhaust	1	62	100104	C-Ring	1
11	100250	Piston Stop	1	63	100046	Plain Washer	1
12	100146	Compression Spring	1	64	100115	Rubber Washer	1
13	100219	Head Valve Washer	1	65	100113	Receiver Spring	2
14	100147	O-Ring	1	66	100079	Step pin	1
15	100148	Head Valve Piston	1	67	100073	O-Ring	1
16	100149	O-Ring	2	68	100066	Roll Pin	1
17	101826	Main Piston Unit	1	69	100092	Spring	1
18	100153	O-Ring	1	70	100267	Feed Pawl	1
19	100154	Cylinder Seal	1	71	100095	Step Pin	1
20	100256	Cylinder	1	72	100297	Nail Support	1
21	100156	O-Ring	1	73	100112	Magazine Post	1
22	100157	Cylinder Ring	1	74	100275	Magazine	1
23	100158	O-Ring	1	75	100168	O-Ring	1
24	100159	O-Ring	1	76	101866	End Cap	1
25	100142	Grommet	1	77	100117	Nut, Elastic Stop	2
26	103132	Frame	1	78	100271	Magazine Cover	1
30	100220	Roll Pin	1	79	100110	Spacer	1
31	100174	Roll Pin	4	80	100111	Spring	1
32	103955	100063 Trigger Valve Unit(CT)	1	81	100216	Contact Arm Cover	1
33	100067	Trigger Unit	1	82	100119	Collar	1
34	100175	Contact Arm Guide	1	MOQ for items in the following categories is 10pcs, order quantities under 10pcs for these items will be adjusted accordingly			
35	100185	Compression Spring	1				
36	100258	Contact Arm	1				
37	100176	Bumper"A"	1				
38	100177	Bumper"B"	1				
39	100180	O-Ring	1	1. Orings – not included in the oring kits			
40	100283	Driver Guide	1	2. Screws, bolts			
41	100296	O-Ring	1	3. Pins - roll pin, solid pins			
42	100260	Nose	1	4. Standard washers – not special washers.			
43	100188	Screw	4	5. Nuts			
44	100179	Straight Pin	1				
45	100045	Screw	2				
46	100078	Rubber Washer	3				
47	100263	Door	1				
48	100080	Hook Dust Cover	1				
49	100265	Dust Cover	1				
50	100194	Step pin	1				
51	100090	Roll Pin	1				
52	100085	Spring, Check Pawl	1				