



PN90

Pneumatic Coil Nailer



OPERATING & MAINTENANCE MANUAL



WARNING

BEFORE USING THIS TOOL, STUDY THIS MANUAL TO ENSURE SAFETY WARNING AND INSTRUCTIONS.

KEEP THESE INSTRUCTIONS WITH THE TOOL FOR FUTURE REFERENCE.

AUGUST 2021

PN90		NOTE: When ordering spare parts. Please state the part name and part number.					
Item	Part NO.	Description	Q'ty	Item	Part NO.	Description	Q'ty
1	100009	Screw, Flat Hd, M8 X 25	1	52	107159	Spring, Contact Arm	1
2	107014	Exhaust Cover Holder	1	53	107002	Contact Arm	1
3	104075	Exhaust Cover	1	54	104105	Dust Shield Plug	2
4	100013	Exhaust Filter	1	55	101396	Dust Cover	1
5	107009	Cylinder Cap Unit	1	56	101365	Feed Pawl	1
6	100208	Screw Socket Hd M6*35	4	57	100340	Step Pin	1
7	101302	Protector	2	58	100336	Spring, Feed Pawl A	1
8	100927	Rubber Protector	2	59	100337	Spring, Feed Pawl B	1
9	103443	Seal, Cylinder Cap	1	60	100011	O-Ring	1
10	101332	Spacer Exhaust	1	61	100098	O-Ring	1
11	107016	Feed Piston Stop	1	62	101369	Feed Piston	1
12	101312	O-Ring	1	63	100206	Spring, Feed Piston	1
13	101311	O-Ring	1	64	100342	Spring, Feed Piston	1
14	101306	Spring	1	65	100205	Stop, Feed Piston	1
15	107012	Head Valve Piston	1	66	100207	Spring Collar	1
16	107160	O-Ring	1	67	100104	C-Ring	1
17	107010	Main Piston Unit	1	68	107004	Contact Arm Cover	1
18	101316	Cylinder Seal	1	69	101407	Magazine Cover	1
19	107008	Cylinder	1	70	100113	Receiver, Spring	2
20	101320	O-Ring	1	71	100110	Spacer	1
21	101319	O-Ring	1	72	100111	Tension Spring	1
22	101318	Cylinder Ring	1	73	101398	Nail Support	1
23	101322	Check Valve	1	74	100112	Magazine Post	1
24	101323	Bumper	1	75	101409	Magazine	1
25	107007	Frame Unit	1	76	100115	Post Retainer	1
26	100966	Spring Pin	4	77	100364	Step Pin	1
27	103955	100063 Trigger Valve Unit(CT)	1	MOQ for items in the following categories is 10pcs, order quantities under 10pcs for these items will be adjusted accordingly			
28	100067	Trigger Unit	1				
29	107003	Contact arm guide	1				
30	101328	Screw Socket Hd M5*40	1	1. Orings – not included in the oring kits			
31	100638	Washer	1	2. Screws, bolts			
32	101336	Washer	1	3. Pins - roll pin, solid pins			
33	101096	Nut, Elastic Stop M5	2	4. Standard washers – not special washers.			
34	100327	O-Ring	1	5. Nuts			
35	101872	End Cap	1				
36	101354	O-Ring	1				
37	101307	Driver Guide	1				
38	100332	O-Ring	1				
39	107001	Nose	1				
40	100925	Screw Socket Hd M8*28	4				
41	100349	Door Latch	1				
42	101377	Spring, Door Latch	1				
43	100078	Rubber Washer	3				
44	100347	Step Pin	1				
45	101362	Pin	1				
46	101383	Pin	1				
47	103276	Rubber Washer	2				
48	101375	Door	1				
49	100085	Spring, Check Pawl	2				
50	101381	Check Pawl Stop	2				
51	100568	Screw Socket Hd M5*30	1				

