

BOSTITCH®

N66BC Cap Nailer



OPERATION & MAINTENANCE MANUAL




WARNING

BEFORE PERFORMING REPAIRS ON THIS TOOL, ALL OPERATORS SHOULD STUDY THIS ILLUSTRATION, AS WELL AS THE PARTS LIST AND OPERATION AND MAINTENANCE MANUAL. OPERATORS SHOULD UNDERSTAND AND FOLLOW THE SAFETY WARNINGS AND INSTRUCTIONS. KEEP THIS ILLUSTRATION WITH THE TOOL FOR FUTURE REFERENCE. IF YOU HAVE ANY QUESTIONS, CONTACT YOUR BOSTITCH REPRESENTATIVE OR DISTRIBUTOR.

N66BC


BOSTITCH CAP NAILER
CLAVADORA DE SOMBRERETES BOSTITCH
CLOUEUSE A CAPUCHONS BOSTITCH



Rebuild Kit N66C-RK
Includes Items 12, 15, 18, 20, 21, 22,
24, 47, 54, & 57

ITEM	USED ON
38	USE OF
28	REBUILD-

***INCLUDED IN REBUILD KIT**



IP1222-1REVC 09/07
 TO BE USED WITH PARTS LIST IP1222-2 AND OPERATION AND MAINTENANCE MANUAL 171130.

N66BC

ITEM	PART NO	DESCRIPTION	QTY RQD	ITEM	PART NO	DESCRIPTION	QTY RQD
1	174041	SCREW-SFHCS-M4X0.7X1	1	57	P2322005100	FEED PISTON BUMPER	1
2	174042	SPACER-EXHAUST COVER	1	58	P2325205262	FEED PISTON COVER	1
3	174043	COVER-EXHAUST	1	59	S15202800	C-RING	1
4	174044	O-RING-41.0MMX1.78MM	1	60	188721	ASSEMBLY-DOOR	1
6	175554	SCREW-SHCS-M5X0.80X3	1	62	P2325204262	UPPER NAIL STOPPER	1
8	P3186300565	MAGAZINE HANGER	1	63	P2320010000	DOOR LATCH	1
9	175554	SCREW-SHCS-M5X0.80X3	4	64	P2820004162	SPRING	1
11	G5400700	DEFLECTOR UNIT	1	65	P2320004100	SPRING	1
12	174050	GASKET-FRAME/DEFLECT	1	66	P2325204062	SECOND NAIL STOPPER	1
13	174049	SEAL-DEFLECTOR	1	67	P2840004100	GROMMET	1
14	174051	SPRING-COMPRESSION	1	68	P2320003900	SPRING	1
15	174053	O-RING-20.8MMX2.4MM	1	69	P2325203862	DOOR COVER	1
16	174052	WASHER-SPECIAL	1	70	S0110412101	HEX.SOC.HD.BOLT	2
17	174054	PISTON-HEAD VALVE	1	71	P2325203662	DOOR PIVOT PIN	1
18	86460	O-RING	1	72	S06S000401	O-RING	1
19	174057	COLLAR-CYLINDER SLEEVE	1	73	S06P000300	O-RING	1
20	174056	O-RING-66.5MMX2.0MM	1	74	S0110625101	HEX.SOC.HD.BOLT	2
21	P2320006600	SEAL RING	1	75	S2710620101	HEX.SOC.HD.BOLT	1
22	S06S003600	O-RING	1	76	P3180000265	FIXED SUPPORT	1
23	G0315900	DRIVER ASSEMBLY	1	77	P2840003200	ASSEMBLY-MAGAZINE	1
24	174058	O-RING-45.5MMX2.0MM	1	78	P2840002366	NAIL HOLDER	1
25	P2322001100	CYLINDER	1	79	P2840002466	ADJUSTING POST	1
28	P1716102300	AIR FITTING	1	81	S1410408400	SELF TAPPING SCREW	3
29	174067	O-RING-45.7MMX2.62MM	1	82	P1960004066	CAP	1
30	P3490000540	END CAP	1	83	P1965204762	SPRING	1
31	TVA6	KIT-TRIGGER VALVE	1	84	P1960004866	CAP	1
32	174070	PIN-SPRING-M3X22MM	1	85	P2840002566	MAGAZINE COVER	1
33	174071	PIN-SPRING-M3X30MM	1	86	P2845202662	PIN	1
34	P2840002766	SAFETY GUIDE	1	87	G7800300	MAGAZINE CYLINDER UN	1
35	P2325202662	SPRING	1	88	P3136302265	MAGAZINE C UNIT	1
36	P2845203062	SPRING HOLDER	1	89	S15101400	C-RING	1
37	174062	STEPPED PIN	1	90	G6300100	CYLINDER B UNIT	1
38	SEQ4	KIT	1	91	P1776301465	PUSHER C	1
39	CNTK1	KIT-CONTACT TRIP CON	1	92	P1710003066	CYLINDER COVER	1
40	174073	O-RING-2.05MMX2.62MM	1	93	P3180001100	PIPE	1
41	174065	NUT-NYLON LOCK-M5X0	1	94	G3101700	SLIDING SEAT UNIT	1
42	1A105201	HEX SOC.HD.BOLT	1	95	P3180001000	MAGAZINE B UNIT	1
43	G4007500	ASSEMBLY-CONTACT ARM	1	96	S31104075	SAFE WASHER	2
44	S0110510101	HEX.SOC.HD.BOLT	2	97	S0110408100	HEX.SOC.HD.BOLT	2
45	P2325205662	MAGAZINE SPACER	1	98	S0110514101	HEX.SOC.HD.BOLT	1
46	P3130000566	GUARD	1	99	G3801865	SAFETY B UNIT	1
47	S06A000500	O-RING	1	100	S0110410101	HEX.SOC.HD.BOLT	1
48	P2325207562	SPRING PIN	1	101	P3185201362	BUSHING	1
49	G7600200	ASSEMBLY-FEED JAW/CO	1	102	175582	SEAT PLATE-HOOK	1
50	174075	BUMPER-PISTON STOP	1	103	175583	HOOK	1
51	851483-S	BOSTITCH O-RING	1	104	175557	O-RING-21.9MMX2.62MM	1
52	S06P000400	O-RING	1	105	175585	CAP-HOOK	1
53	P2840001065	NOSE	1	106	175586	RING-RETAINING	1
54	S06P000900	O-RING	1	800	100679	LUBE (1LB.CAN)	1
55	P2325504962	FEED PISTON	1	800	100653	LUBE (2CC)	1
56	P2325205062	SPRING	1				