



HN120

Concrete Nailer



OPERATING & MAINTENANCE MANUAL



WARNING


BEFORE USING THIS TOOL, STUDY THIS MANUAL TO ENSURE SAFETY WARNING AND INSTRUCTIONS.

KEEP THESE INSTRUCTIONS WITH THE TOOL FOR FUTURE REFERENCE.

AUG 2023

HN120

EXPLODED VIEW AND SPARE PARTS LIST



Parts List MAX HN120 Concrete Nailer

Part No	Part Code	Description	Part No	Part Code	Description
1	HN10325	EXHAUST COVER	65	BB40444	SCREW 8X30
2	BB41701	SCREW 6X8	66	FF31261	PARALLEL PIN 1261
3	BB40227	SCREW 6X35	67	HN10302	DOOR OPENING/CLOSING PLATE
4	HN70095	CYLINDER CAP UNIT	68	HN10301	DOOR
5	HH14040	O-RING AS568-040	69	KK23376	COMPRESSION SPRING 3376
6	HH11120	O-RING ARP568-009	70	CT10191	SWTICHING BAR
7	HN10275	PISTON STOP	71	KK33090	TORSION SPRING 3090
8	KK23516	COMPRESSION SPRING 3516	72	FF42214	STEP PIN 2214
9	CN31892	HEAD VALVE WASHER	73	HN10303	DOOR OPENING/CLOSING LEVER
10	HH19708	O-RING 1A2.6X39.5	74	FF41528	STEP PIN 1528
11	HH11157	O-RING AS568-136	75	KK33197	TORSION SPRING 3197
12	HN10274	HEAD VALVE PISTON	76	CT10226	LEVEL RETAINING RUBBER
13	HH11803	O-RING P36	77	BB40457	SCREW 6X38
14	HN10279	MAIN PISTON UNIT	78	HN10309	NAIL GUIDE
15	HN10278	CYLINDER SEAL	79	HN10297	NOSE TIP
16	HN10276	CYLINDER A	80	HN10213	FEED FINGER RETAINER
17	HH12108	O-RING 1AG60	81	HN10289	CONTACT ARM UNIT
18	HN81025	FRAME ASSY	82	HN10292	ATTACHMENT A
19	HN10755	CAUTION LABEL	83	HN10293	ATTACHMENT B
20	CN34088	TRIGGER LOCK LEVER	84	KK29166	COMPRESSION SPRING 9166
21	HN10310	GRIP COVER A	85	HN10287	ARM GUIDE UNIT
22	HN10322	BUFFER SEAT A	86	KK24072	COMPRESSION SPRING 4072
23	EE31105	PLANE WASHER 1-6	87	HN10304	DOOR OPENING/CLOSING FINGER
24	CC00402	NUT M6	88	JJ22408	C-RETAINING RING 24
25	HH12118	O-RING 1AG35	89	HN10299	SPRING COLLAR
26	HN10313	END CAP	90	CN31755	FEED PISTON STOP
27	HN70264	AIR PLUG H-FPM	91	KK23517	COMPRESSION SPRING 3517
28	HN10316	END PLUG CAP	92	HH11106	O-RING 1AP16
30	HN10756	NAME LABEL (USA)	93	HN10298	FEED PISTON
31	FF21201	ROLL PIN 2.5X10	94	FF51613	HOLLOW PIN
32	HN10327	TRIGGER LOCK DIAL	95	HN12401	WARNING LABEL
33	KK23507	COMPRESSION SPRING 3507	96	HN81452	MAGAZINE CAP ASSY
34	FF21235	ROLL PIN 3X30	97	FF41281	STEP PIN 1281
35	HN10311	GRIP COVER B	98	KK33218	TORSION SPRING 3218
36	HN10323	BUFFER SEAT B	99	HN10731	MAGAZINE HOLDER
38	HH21002	SEAL 002 NBR	100	FF21101	ROLL PIN 3X12
39	KK33189	TORSION SPRING 3189	101	HN10308	MAGAZINE HOOK
40	HH11159	O-RING ARP568-016	102	HN10737	MAGAZINE LOCK LEVER
41	HN10326	TRIGGER VALVE CAGE	103	HN10736	MAGAZINE
42	HH11151	O-RING ARP568-013	104	FF41599	STEP PIN 1599
43	HN10283	TRIGGER VALVE HOUSING	105	EE39609	RUBBER WASHER 1.8X6X2
44	FF30161	PARALLEL PIN 161	106	BB71504	SCREW 6X35
45	HH11138	O-RING 1AP20	107	HN10330	ATTACHMENT C UNIT
46	HH11119	O-RING 1AP6	108	HN10211	DUST COVER
47	HH11802	O-RING P7	109	CN31083	DUST COVER FITTING
48	CN33627	PILOT VALVE	110	CN32170	COLLAR
49	HH11113	O-RING 1AP9	111	HN10501	GUIDE HOLDER
50	KK23129	COMPRESSION SPRING 3129	112	BB40436	SCREW 6X14
51	HN10328	TRIGGER VALVE STEM	113	HN10502	NAIL NOSE GUIDE
52	HH11901	O-RING 1B1.4X2.5	116	HN10753	NAIL NOSE GUIDE B
53	HN10284	TRIGGER VALVE CAP	117	HN10757	TRIGGER LOCK SEAL
54	HN10286	CONTACT LEVER	120	TA17024	END CAP FILTER KM-23
55	HN81029	TRIGGER UNIT	121	BB40807	BOLT 5X6
56	FF22402	ROLL PIN 3X16	122	HN10521	NAIL NOSE GUIDE C
57	EE39602	RUBBER WASHER 7	201	HN81032	TRIGGER VALVE KIT
58	HN10300	FEED PAWL	202	HN81033	O-RING KIT
59	KK33190	TORSION SPRING 3190			
60	FF41598	STEP PIN 1598			
61	HN10277	CYLINDER B			
62	HN10282	BUMPER			
63	HN10296	DRIVER GAUGE			
64	HN10294	NOSE UNIT			Aug-23