






80.16SL

USE, MAINTENANCE & SPARE PARTS MANUAL




TECHNICAL DATA		Cod. 1146040
Usable lengths mm	4 ÷ 16	Type of Fastener 80  0,65x0,95  Crown: .500" (1/2") Gauge: 21
Magazine capacity, no. of fasteners	145	
Working pressure	4 ÷ 6 bar 60 ÷ 90 psi	
Air consumption litres/shot	0.18	
Weight kg	1.00	
Dimensions mm	223 x 43 x 198	
Sound pressure at work station	81 dB(A)	
Emitted sound power	88 dB(A)	March 2021
Vibratory emissions on handle	<2.5 m/s ²	

SPARE PARTS



EQUIPMENT



07.30



D01









80.16 SL

cod. 1146040

SPARE PARTS

Cod.	Description
00.04	O-Ring
00.06	O-Ring
00.12	O-Ring
00.13	O-Ring
00.14	O-Ring
00.26	O-Ring
00.27	O-Ring
00.35	O-Ring
01.21.1	Gasket
01.29	O-Ring
01.33	O-Ring
04.06.5	Screw
04.10	Screw
04.12	Screw
04.16	Screw
04.20	Screw
04.50	Screw
07.05	Ball
07.30	Hex. bar wrench
09.02	Elastic ring
20.00	Body
22.07	Head
23.02	Extension
24.00	Silencer
25.04	Exhaust deflector
26.08	Cylinder
28.00	Gasket
32.05	Bumper
39.00	Exhaust gasket
40.04	Valve ass'y
45.04	Ring
54.03	Trigger valve
55.06	Bush
70.04	Guard
72.03.3	Support
76.04	Pin
76.14	Pin
76.45	Pin
80.08	Trigger
81.09	Trigger
81.15	Safety
90.07	Spring
90.10	Spring
91.03X	Spring
92.01X	Spring
93.02	Spring
21.04.80	Driver
53.00.80	Magazine
62.04.80	Slider
70.00.80	Pusher
81.04.80	Nose
91.04.80	Nose plate
D01	Oiler

O - R I N G S



00.70.5

80.16 SL

cod. 1146040

Indice di modifica
Upgrade number

4